

CORRECT FLAME 1.




4. WAVING BLUE FLAME



CHECK FOR


 DRAFTS AT PILOT LOCATION

NOISY, LIFTING, BLOWING 5. HARD SHARP FLAME 2.



CHECK FOR

- HIGH GAS PRESSURE
- WRONG ORIFICE




CHECK FOR

- HIGH GAS PRESSURE
- ORIFICE TOO SMALL


3. LAZY YELLOW FLAME

6. SMALL BLUE FLAME



CHECK FOR

- CLOGGED PRIMARY AIR **OPENING**
- LOW GAS PRESSURE
- CLOGGED ORIFICE



CHECK FOR

- WRONG ORIFICE
- LOW GAS PRESSURE
- CLOGGED PILOT LINE